



GPIO Function Reference

37: QEO_A/PWMOUT0/AUXDIO1 (phase leader)
38: QEO_B/PWMOUT0/AUXDIO0
39: QEO_A/PWMOUT1/AUXDIO3
40: QEO_B/PWMOUT1/AUXDIO2